X-ray Lab, Room 117



STUDENTS-HUB.com





STUDENTS-HUB.com

Electromagnetic Spectrum

X-rays are electromagnetic radiation of exactly the same nature as light but of very much shorter wavelength



Unit of measurement in x-ray region is Å and nm. 1 Å = 10^{-10} m, 1 nm = 10 Å = 10^{-9} m

X-ray wavelengths are in the range 0.5 - 2.5 Å. Wavelength of visible light ~ 6000 Å.

STUDENTS-HUB.com

Properties of Electromagnetic Waves

 Electromagnetic radiation can be considered as wave motion in accordance with classical theory.

$$E = A \exp(i\omega t - \varphi)$$

A – amplitude of the wave ω – frequency ($\omega = 2\pi\nu$) ϕ – phase ($\phi = \nu$ t)

According to the quantum theory electromagnetic radiation can also be considered as a particles called *photons*. Each photon has associated with it an amount of energy:

$$E = hv$$

 $h = 6.63 \times 10^{-34} \text{ Js}$

STUDENTS-HUB.com

Intensity – the rate of flow of electromagnetic radiation energy through unit area perpendicular to the direction of motion of the wave.



Relationship between wavelength and frequency:

$$\lambda = C/v$$

c – velocity of light (
$$\sim 3 \times 10^8$$
 m/s)

X-ray Spectrum



- The loss of energy of the electrons due to impact is manifested as x-rays.
- X-ray radiation is produced in an x-ray tube.

Most of the kinetic energy of the electrons striking the target is converted into heat, less than 1% being transformed into x-rays.

$$E_{K} = eV = \frac{1}{2}mv^{2}$$

e – electron charge (1.6×10⁻¹⁹ C)

- E_{κ} kinetic energy, V applied voltage,
- m mass of the electron (9.11×10⁻³¹ kg),
- v- electron velocity (m/sec)



Uploaded By: Jibreel Bornat

STUDENTS-HUB.com



STUDENTS-HUB.com

Properties of the Continuous Spectrum

Smooth, monotonic function of intensity vs wavelength.

The intensity is zero up to a certain wavelength – *short wavelength limit* (λ_{SWL}) . The electrons transfer all their energy into photon energy:



STUDENTS-HUB.com

Properties of the Continuous Spectrum

The total x-ray energy emitted per second depends on the atomic number Z of the target material and on the x-ray tube current. This total x-ray intensity is given by

$$V_{cont.} = AiZV^{m}$$

- A proportionality constant
- i tube current (measure of the number of electrons per
 - second striking the target)
- m constant \approx 2

STUDENTS-HUB.com



The Characteristic Spectrum

- The characteristic peak is created in when a hole in the inner shell, created by a collision event, is filled by an electron from higher energy shell.
- Let a *K*-shell electron be knocked out -- the vacancy can be filled by an electron from the *L*-shell ($K\alpha$ radiation) or the *M*-shell ($K\beta$ radiation).



Properties of the Characteristic Spectrum

Usually only the *K*-lines are useful in x-ray diffraction.

Κα

- There are several lines in the K-set. The strongest are $K\alpha_1$, $K\alpha_2$, $K\beta_1$.
- α_1 and α_2 components are not always resolved $K\alpha$ doublet. $K\alpha_1$ is always about twice as strong as $K\alpha_2$, while ratio of $K\alpha_1$ to $K\beta_1$ averages about 5/1.

		Some Commonly Used X-ray <i>K</i> wavelengths (Å)						
units)	Κα1	Element	<i>K</i> α (av.)	Κ α ₁	Κ α ₂	Κ β ₁		
Celative		Cr	2.29100	2.28970	2.29361	2.08487		
Kβ		Fe	1.93736	1.93604	1.93998	1.75661		
	Κα2	Со	1.79026	1.78897	1.79285	1.62079		
		Cu	1.54184	1.54056	1.54439	1.39222		
		Мо	0.71073	0.70930	0.71359	0.63229		
0.02 0.04 0.06 0.08 0.10 STUDENTS-HUB.COM/appelength (nr					aded By: Jil	• • • • • • • • • • • • • • • • • • • •		

Properties of the Characteristic Spectrum

The intensity of any characteristic line depends both on the tube current i and the amount by which the applied voltage V exceeds the critical excitation voltage for that line. For a K-line:

$$U_{K-line} = Bi(V - V_K)^n$$

B – proportionality constant

 V_{K} – the *K* excitation voltage

n ≈ 1.5

Characteristic lines are also very narrow, most of them less than 0.001 Å wide (Full Width At Half Maximum).

High intensity and narrow K-lines makes x-ray diffraction possible, since it generally requires the use of monochromatic radiation.

Moseley's Law

The wavelength of any particular line decreases as the atomic number of the emitter is increased.

• There is a linear relation between the square root of the line frequency v and the atomic number Z:



X-ray Absorption

When x-rays encou and partly absorbed	nter any form of matter, they are partly transmitted
It was found experi	
	$I \propto x$
I – intensity	
x – distance	
In differential form	
	$-\frac{dI}{I} = \mu dx$
	$-\frac{1}{I} = \mu \alpha x$
where u - is <i>linear abs</i>	orntion coefficient

where μ - is *linear absorption coefficient*

STUDENTS-HUB.com

X-ray Absorption

After integration

$$I_x = I_0 e^{-\mu x}$$

- I_0 incident beam intensity
- I_{χ} transmitted beam intensity
- Let's introduce mass absorption coefficient μ/ρ (ρ density). It is constant and independent of physical state (solid, liquid, or gas). Then

 $I_x = I_0 e^{-(\mu/\rho)\rho x}$

• Values of the mass absorption coefficient μ/ρ are tabulated.

Mass Absorption Coefficient

The mass absorption coefficient of the substance containing more than one element is a weighted average of the mass absorption coefficients of its constituent elements.

• If w_1 , w_2 , w_3 , ... are the weight fractions of elements 1, 2, 3, ... and $(\mu/\rho)_1$, $(\mu/\rho)_2$, $(\mu/\rho)_3$, ... their mass absorption coefficients then



STUDENTS-HUB.com

Properties of the Absorption Coefficient



STUDENTS-HUB.com

λ (angstroms) Uploaded By: Jibreel Bornat

Properties of the Absorption Coefficient

Incident x-ray quanta with energy W_K can knock out an electron from K atomic shell.



X-ray Filters



X-ray Filters

• The filtration is never perfect. Thicker the filter better the suppression of K β component but this also results in weaker K α . There is always a compromise.

	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	K	Ca	Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu	Zn	Ga	Ge
	potassium	calcium	scandium	titanium	vanadium	chromium	manganese	iron	cobalt	nickel	copper	zinc	gallum	germanium
	39.056	40.078(4)	44.956	47.867	50.942	51.906	54.938	55.145(2)	56.933	56.693	63.546(3)	65.38(7)	69.723	72.630(8)
· · · · · · · · · · · · · · · · · · ·	37 Rb rubidium 85.468	38 Sr strontium 87.62	39 Y yttrium 88.906	40 Zr zirconium 91.224(2)	41 Nb niobium 92.906	42 Mo molybdenum 96.95	43 Tc technetium	44 Ru ruthenium 101.07(2)	45 Rh rhodium 102.91	46 Pd palladium 106.42	47 Ag silver 107.87	48 Cd cadmium 112.41	49 In indium 114.82	50 Sn tin 118.71

Filters for Suppression of $K\beta$ Radiation

	Target	Filter	Incident beam* <u>I(Kα)</u> I(Kβ)	Filter thic $\frac{I(K\alpha)}{I(K\beta)}$ in trans	$=\frac{500}{1}$	$\frac{I(K\alpha) \text{ trans.}}{I(K\alpha) \text{ incident}}$
				mg/cm ²	in.	
	Мо	Zr	5.4	77	0.0046	0.29
	Cu	Ni	7.5	18	0.0008	0.42
	Co	Fe	9.4	14	0.0007	0.46
	Fe	Mn	9.0	12	0.0007	0.48
STUDEN	Cr TS-HUB.com		8.5	10	0.0006	0.49 Uploaded By: Jibreel Bornat

X-ray Sources

The tube must have:

- source of electrons
- high accelerating voltage
- metal target
- X-ray tube types:

U

- Gas tube the original x-ray tube \Rightarrow **obsolete**.
- Filament tube most common type of laboratory x-ray source.

Filament

Wout

₩in



Target

+

Filament X-ray Tube

- Invented by Coolidge in 1913.
- The most widely-used laboratory X-ray source.
- Major components are a water-cooled target (anode) and a tungsten filament (cathode) that emits electrons.
- A high potential (up to 60 kV) is maintained between the filament and the anode, accelerating the electrons into the the anode and generating X-rays.
- Cooling water is circulated through the anode to keep it from melting (>99% of input power generates heat).
- Interior of the tube is evacuated for the electron beam; thin beryllium windows transmit the X-rays.



Filament X-ray Tube



Ceramic Diffraction X-ray Tube – Physical View

STUDENTS-HUB.com

Aspects of X-ray tube design and operation

- The electron beam produced and controlled by the current that is passed through the filament.
- Stable high voltage and filament current power supplies are needed (old-style transformers \rightarrow high frequency supplies).
 - Power rating: applied potential × electron beam current (example: 50 kV and 40 mA \rightarrow 2 kW).
- Maximum power determined by the rate of heat removal (without water, a tube can be destroyed in seconds \rightarrow flow interlocks).
 - The anode is electrically grounded, while the filament is kept at negative kV's (the water-cooled anode won't short out, and the filament is protected by glass insulation).
- Beryllium windows are fragile and toxic:
 - don't shock (mechanically or thermally).
- STUDENTS-HUB.com (and don't taste!).

Selecting X-ray tube for Application

- The shape of the incident beam depends on the focal projection of the filament onto and from the anode material.
- X-ray beams that are parallel with wide projection of the filament have a focal shape of a *line*.
- X-ray beams that are parallel with the narrow projection of the filament have an approximate focal shape of a square, which is usually labeled as a *spot*.
- These two focal projections are 90 ° apart in the plane normal to the filament-anode axis.
- As the angle from the anode surface is increased, the intensity of the beam increases, but the spot also becomes less focused.



Selection of XRD Tubes According to Anode Material

Anode Material	Atomic Number	Application		
Copper (Cu)	29	Suitable for most diffraction examinations - most widely used anode material.		
Moly (Mo)	42	Preferably used for examinations on steels and metal alloys with elements in the range Titanium (Ti) (atomic No. = 22) to approx. Zinc (Zn) (atomic No. = 30)		
Cobalt (Co)	27	Often used with ferrous samples, the Iron (Fe) fluorescence radiation would cause interference and cannot be eliminated by other measures.		
Iron (Fe)	26	Examination of ferrous samples. Also for use with minerals where Co and Cr tubes cannot be used.		
Chromium (Cr)	-24	Used for complex organic substances and also radiographic stress measurements on steels.		
Tungsten (W)		Used where an intensive white spectrum is of more interest than the characteristic.		

Rotating Anode X-ray Generator

- The maximum power of an X-ray generator can be greatly increased if a new cooled surface is continually presented to the electron beam
- Typical rotating anode generators operate from 12 kW to 18 kW (60 kV/300 mA); specialized generators will go up to 90 kW (60 kV/1500 mA)





Rigaku rotating anode

Rotating Anode X-ray Generator



Rotating anode tube housing





Tube housing designs

STUDENTS-HUB.com

Aspects of Rotating Anode X-ray

Generators

- The anode (about 100 mm diameter × 40 mm wide) rotates at speeds of 2400 rpm up to 6000 rpm.
- Exceptional dynamic balancing is required.
- Rotating anode resides in a high vacuum environment (better than 10⁻⁶ Torr) with both rotation and water feedthroughs.
 - Impressive water flow rates are necessary.
 - Electron beam currents exceeding 0.3 A at 60 kV.

Rotating anode generators are expensive and require high maintenance but are the most powerful laboratory X-ray source available – higher X-ray fluxes require a synchrotron.

Microfocus x-ray source





STUDENTS-HUB.com

Synchrotron Radiation Sources

Synchrotron radiation is generated when the charged particles are accelerated perpendicular to their trajectory. This is usually achieved by magnetic fields, e.g. bending magnets or periodical magnetic devices (socalled insertion devices). Due to the relativistic energy of the particles the generated light has superior properties:

- The emitted continuous spectrum is of high intensity.
- The natural **divergence** of the radiation is very small and collimators further reduce these values.
- Distinct linear or circular polarization, which can be selected depending on the application.



Synchrotron Radiation Sources

Stanford Synchrotron Radiation Laboratory

A national user facility for academia, industry, and national laboratories



Advanced Photon Source

Apple's new campus





⊢ 100 ft

STUDENTS-HUB.com

Synchrotron Radiation Sources



Synchrotron Radiation Sources



X-ray Safety

Radiation safety depends on YOU!

STUDENTS-HUB.com
General

A fundamental precept of radiation safety is that the individuals must assume the responsibility not only for their own safety, but must ensure that their actions do not result in hazards to others.

General

Anna an	on a hana a a			ana ang kana	and the second	a succession de conseguero de la conseguero	
- I D I				ietic	n – 1	5 - 45 -	
	0.0 T T	om	200		1220	12110	
		ULH	44.14		n a u		,
			_				

1 μeV
l.meV
1 eV
2 eV
3 eV
4 eV
100 KeV
l MeV

X-ray Diffractometers

This is an example of an unenclosed (open) x-ray diffractometer. As the open xray beam of such an instrument can be extremely hazardous, it is far preferable to enclose the entire x-ray apparatus.

PHILIPS ANALYTICAL NORELCO X-RAY DIFFRACTOMETER GONIOMETER SERIAL NUMBER 2 PRODUCED 1948 PHILIPS ELECTRONIC INSTRUMENTS MOUNT VORION, N.Y.





STUDENTS-HUB.com

X-ray Diffractometers

 This is another example of an unenclosed (open) x-ray diffractometer



STUDENTS-HUB.com

- This is an example of properly enclosed and interlocked x-ray diffractometer.
- If a panel is opened while the xray diffractometer is being used, the interlock will either shut off the x-ray or close the shutter, preventing accidental exposure to personnel.
 - The leaded glass windows not only afford a view of the x-ray apparatus, but also provide shielding against radiation.



STUDENTS-HUB.com

Causes of Accidental Exposures

Although most x-ray workers do not receive any measurable radiation above background, accidents related to x-ray devices have occurred when proper work procedures have not been followed. Failure to follow proper procedures has been the result of

- rushing to complete a job,
- fatigue,
- illness,
- personal problems,
- lack of communication, or
- complacency.

Four Main Causes of Accidents



Poor equipment configuration, e.g. unused beam ports not covered, interlock system is not engaged.

Manipulation of equipment when energized, e.g. adjustment of samples or alignment of optics when x-ray beam is on.





Reducing External Exposure



Three basic ways to reduce external exposure to radiation are to

- minimize time,
- maximize distance, and
- use shielding.



STUDENTS-HUB.com

Monitoring X-ray Exposure

Finger Dosimeters

- Ring dosimeters provide accurate readings for the radiation you are receiving.
- By regularly reviewing Dose Exposure Reports, you'll be able to monitor radiation levels and limit the amount of exposure to your extremities.
- All rings consists of one natural lithium fluoride element and offer immersible, bar coded single-piece construction.





Let say you are exposed to a dose of 100 mrem/year... STUDENTS-HUB.com

Life Expectancy Days Lost

Average estimated days lost due to daily activities

Occupation	Days of Life Lost	
Being an unmarried male	3,500	
Smoking (1 pack/day)	2,250	
Being an unmarried female	1,600	
Being a coal miner	1,100	
Being 25% overweight	777	
Drinking alcohol (US average)	365	
Being a construction worker	227	
Driving a motor vehicle	207	
All industry	60	
Being exposed to 100 mrem/year of radiation for 70 years	10	
Drinking cofee	6	

Exposure Limits

	rem/	rem/year	
~~ ~	General	Stanford	
Adult workers	5.0	0.5	
Eye lens	15.0	1.5	
Skin, organ, extremities	50.0	5.0	
Minors	0.5	0.05	
Declared Pregnant Women	0.5	0.05	
Members of the Public	0.1	0.01	

STUDENTS-HUB.com

Exposure Limits

Common Radiation Exposures

3.0 mrem	
150 – 300 mrem/year	
15 – 65 mrem/view	
60 – 135 mrem/view	
3,000 – 6,000 mrem	

Biologically Significant Radiation Exposures

	mrem
Risk of contracting cancer increased 0.04%	1,000
Temporary Blood Count Change	25,000
Permanent sterilization in men	100,000
Permanent sterilization in women	
Skin Erythema	300,000
TS-HUB.com	Uploaded By: Jibreel B

Radiological Signs



CAUTION

X-RAY PRODUCED WHEN

ENERGIZED

CAUTION

DO NOT INSERT ANY PART OF THE BODY WHEN SYSTEM IS ENERGIZED — X-RAY

STUDENTS-HUB.com

Doug Menke

- Email: <u>dmenke@stanford.edu</u>
- Department : Environmental Health and Safety (EH&S)
- Work phone: (650) 723-4723
- Work address: Environmental Health & Safety
 - 480 Oak Road
 - Stanford, California 94305-8007

http://www.stanford.edu/group/glam/xlab/Main.htm

http://www.stanford.edu/group/glam/xlab/Safety/Authorization.htm



http://web.stanford.edu/group/glam/xlab/Safety/Authorization.htm

C 🗋 web.stanford.edu/group/glam/xlab/Safety/Authorization.htm

← ⇒

X-ray Lab	Stanford University X-ray Safety Geballe Laboratory for Advanced Materials User Authorization Links
News Technique X'Pert 1 X'Pert 2	 Steps to obtain access to the X-ray Lab: Read <u>Safety Manual</u>. Complete <u>Safety Questionnaire</u>. Contact <u>Doug Menke</u> and make an appointment at Environmental Health & Safety Dept. (<u>EH&S</u>). Obtain <u>Safety Certificate</u> from EH&S and bring copy to X-ray Lab.
Laue Software	 Setup Badger account by joining <u>Stanford Nano Shared Facilities (SNSF)</u>. Contact <u>X-ray Lab manager</u> and signup for x-ray diffraction training.
X-ray Safety Links Contact Info	
MATSCI 162/172 STUDENTS-HUB	3.com Uploaded By: Jibreel Born