

# Electronic Circuits 1



ENEE 2303

**Mr. Mohammad AL-Jubeh**

# Electronic Circuits



- ▶ We encounter electronics in our daily life in form of telephones, radios, television, audio equipment, home appliances, computer and equipment for industrial control and automation .





- ▶ The field of electronics deals with the design and applications of electronic devices .



# Electronics Devices

## ► Diodes

- a) Rectifier diode
- b) Zener diode
- c) Light Emitting Diode (LED)



## ► Transistors

- a) Bipolar Junction Transistor (BJT)
- b) Field Effect Transistor (FET)



## ► Integrated Circuit (IC)




# Diode

- It is an electronic device with a single p-n junction and it has the ability to conduct current in one direction while blocking current in the other direction.








- Circuit Symbol :



- Physical construction








# Semiconductor


- ▶ Electronic devices such as diodes, transistors and integrated circuits are made of a semiconductor material .
- ▶ Semiconductors : materials whose resistance lies between **low** resistance of **conductor** and the **high** resistance of insulator .



# Atomic structure




# Covalent bond






# Covalent bond

- ▶ A silicon (Si) atom with its four valence electrons shares an electron with each of its four neighbors
- ▶ This effectively creates eight shared valence electrons for each atom and produces a state of chemical stability .
- ▶ Also, this sharing of valence electrons produce the covalent bonds that hold the atom together; each valence electron is attracted equally by the two adjacent atoms which share it .



# Covalent bond in silicon crystals


- At absolute zero degree ( $-273\text{ }^{\circ}\text{C}$ ) all valence electrons are tightly bonded to their atoms and there is no free electrons, so the silicon behave as an insulator .





# Rupture of the a covalent bond

- ▶ When an electron becomes free that is unattached to any atom, a vacancy is left in the valence band within the crystal . This vacancy is called **hole** .
- ▶ For every free **electron**, there is one **hole** .
- ▶ One broken covalent bond → one free **electron** + one **hole**
- ▶ At room temperature there is one broken covalent bond for every  $3 \times 10^{12}$  pure Si atoms .
- ▶ At room temperature there are few available charge carriers (free **electrons** + **holes**)



# Hole motion

- ▶ When a valence **electron** moves left to right to fill a **hole** while leaving another **hole** behind, the hole has effectively moved from right to left.

